
# Smart Pet Robot Camera Quick Operation Manual






#### Instructions for DH013

Note: The low-power battery camera has a built-in battery by default. Please charge the battery before using the camera for the first time.

(Charging time is about 5-8 hours)

## 1.Product Description



# 2.Device Connection

#### Notes on network distribution:

- This camera does not support 5GHz WiFi. Please connect via 2.4GHz WiFi.
- Check that DHCP is enabled on your router.

#### Step 1 SriHome App Installation

Method 1: Search for "SriHome" on Google Play or iOS App Store.


Method 2: Scan the QR code to download "SriHome" App.



#### Step 2 Registration & Login on SriHome App

#### Step 3 Power on the camera

Turn the power switch to ON and wait for the camera to start up.




In about 10 seconds, the camera will emit a continuous "di-di-di" network configuration prompt tone. Follow the following operation procedures to set up the WiFi network for the camera.

Note: If there is no continuous"beep" sound, keep holding the "RESET" button for 5 seconds until you hear a long "Beep"

#### Step 4 Add camera to SriHome APP

When you hear the continuous "beep", follow the instructions of the SriHome App to add the device, as in the figure:




#### Introduction for monitoring interface:

13. ← Pan&Tilt App Settings 5. 袋 Settings 9. 

1 Local record 2. ☐ Scan code 10. Screenshots Intercom 11. [[]) Speaker 3. E Split Screen 7. SD Resolution 15. Playback 4. + Add 8. **(L)** Up & down 12. 9% Pet 16. 🛇 Preset

# 3. Pet-playing function




Note: After selecting the pet-playing mode, you need to click the switch to start

#### FAQ1: Alarm and Battery Saving Settings

#### 1. Alarm Setting

Note: When the camera triggers an alarm and wakes up, will push notifications to the APP, You need to enable the following settings to receive the notifications.

- 1-1. Go to the mobile APP permission management interface and enable receive notification from the SriHome APP.
- 1-2. Enable Alarm Notifications on SriHome App(As shown below)



### 2. Battery Saving Setting

**Detection frequency:** The larger the number, the less power the battery consumes.

PIR Time Schedule: Customize the PIR detection time to reduce power consumption. You can set the time as needed.

Low Battery Alerts: Open the APP to set the camera low battery reminder display.

### FAQ2: Share the camera with other users

The device supports multi-user viewing. Download SriHome App to register an account, and then the administrator can share permissions to watch.

- 1. Administrator operation: Administrator logs in to SriHome App. click Settings button->Visitor Management->Add->Select operator/visitor->Scan QR code New user App ID QR code (Figure 5)
- -> Remarks name -> Next step is completed (Figure 1-Figure 3)
- 2. Authorized users: Return to the APP monitoring interface and scroll down to refresh to view the monitoring(Figure 6)



#### How to find the user APP ID in the mobile app?




### FAQ3: How to install the Pet Stick

Supports installing a pet playstation for entertainment with your pet. Installation steps are as follows:

- 1. Hang the feather into the slightly larger ring at one end of the wire.
- 2. Insert the screw into the slightly smaller ring at the other end of the wire.



3. Align the screw with the small hole on the top of the product and tighten it with a screwdriver.



## Other FAQ

# Question 1: Why there is no network configuration prompt sound when the camera is turned on?

Please press and hold the reset button on the back of the camera for 5-10 seconds until the camera emits a "beep" prompt sound. If it still does not work, you can charge the camera (it is recommended to charge for 6 hours)

# Question 2: When using the APP to add a camera, it shows that the device has been bound and cannot be added normally.

Please press and hold the reset button on the back of the camera for 5-10 seconds until the camera emits a "beep" prompt sound. Wait for the camera to emit a "beep beep" prompt sound again, and then use the APP to add the device again.

# Question 3: Changing the home Wi-Fi account or password causes the camera to go offline.

Please press and hold the reset button on the back of the camera for 5-10 seconds until the camera emits a "beep" prompt sound. Wait for the product to emit a "beep beep" prompt sound again, and then use the APP to add the device again.

#### Question 4: The app prompts that the camera is offline.

- 1. Check whether the indoor Wi-Fi signal is stable.
- 2. Check whether the camera is too  $\tilde{\text{far}}$  from the router. Try placing the camera closer to the router.